

CONTENTS SUPPLIED

EACH FLAG KIT INCLUDES :

- (a.) Carrying Case (1)
- (b.) Pole (2,3, or 4)
- (c.) Flag (1)
- (d.) Bungee Cord w/Clip (1)
- (e.) Ground Stake (1)



(b) (Large 5x) (14ft TD / 15ft FB)




(b) (Medium 4x) (7ft TD / 9ft TD / 11ft TD / 12ft FB)



(b) (Small 3x) (8ft FB / 10ft FB)



Key info *FB - Feather Banner
TD - Tear Drop Banner



(c) Feather

(c) Teardrop



(d)



(e)

REQUIRED TOOLS

You will need a hammer to install the ground stake




FEATHER & TEARDROP FLAGS




Assembly Instructions

IMPORTANT I.



*Do not install near trees, wires, poles or buildings
*Allow a minimum of 5ft. between banner pole and nearest object

IMPORTANT II.




INSTALL GROUND STAKE

For proper installation hammer the top of the stake, not the flag mount

Hammering the wrong area will damage the ground stake!

STEP 1

CONNECT POLES




Black rim always on bottom

Black rim always on bottom

Connect poles. Arrange all poles in order from smallest to largest before assembly.

STEP 2


INSTALL FLAG




Slide banner on assembled poles starting on smallest end. Make sure the pole is completely inside the reinforced pocket at the end of the sleeve.

STEP 3

String bungee cord through the flag grommet




STEP 5



Tighten the knot with tension but do not over tighten

STEP 4


Tie bungee ends



STEP 6



Once desired height is reached, turn hook to tighten clasp to pole.



INCLEMENT WEATHER

TAKE YOUR FLAG DOWN DURING INCLEMENT WEATHER OR HIGH WINDS. FLAGS CAN WITHSTAND SUSTAINED WINDS UP TO 25MPH.

DO NOT FLY YOUR FLAG IN EXTREME WINDS (24-31MPH OR 6FT AND HIGHER) AND/OR THUNDERSTORMS. DO NOT USE NEAR OVERHEAD WIRES. EXERCISE CAUTION TO PREVENT INJURY.